



Assembly Instruction For 12059

1. Insert the tube and shade on the socket.

